

## 1003-10-1 Discharge Basket Assembly

<u>Ref</u>	<u>Part No.</u>	<u>Description</u>	<u>Parts – Assembly</u>	<u>Will Fit SN</u>	<u>Remarks</u>
1	BT-0013	Belting, Shield, Inner Discharge & Basket	1		
2	191-927	Discharge Elevator Mount, Rear	1	19101	
3	191-928	Bracket for front panel-elevator mount	2	19101-	
4	191-937	Discharge, Tomato guard rear	1	19101-	
5	191-921	Panel, Rear Discharge	1	19101-	
6	194-925	Discharge Valve	1	19401-	
7	191-917	Discharge Cylinder Mount	1	19101-	
8	193-922	Deflector	1	19301-	
9	192-936	Tomato Guard, Front Discharge	1	19201-	
10	192-936A	Discharge basket, Front Extension	1	19201-	
11	193-920A	Front Discharge Panel Extension	1	19301-	
12	193-920	Front Discharge panel	1	19301-	
13	191-926	Discharge Elevator Mount, Front	1	19101-	
14	PAN-920C	Panel, Access [Red]	1	19301-	
15	RLT-535-228	5" Flange Roller 2.2WF x 3 1/2" dia, 1/2" bore	2		
16	RLA-010-0108	Spindle / Standoff for Urethane Roller (heat treated)	3	19101-	
17	RLG-040-1016	4" Urethane Roller	3		
18	RLT-535-128	Narrow Flange Roller 1.2 WF 3.5 dia, 1/2" Bore	2		
19	RLA-000-118	Standoff, 1/2" X 1 1/8"	2		
20	RLR-040-108	4" Flat Roller	2		
21	EL-1120	Machine Leveler, Complete w/ Decal & Mount	1		
800	DC-0040	Decal, Level Control	1		
801	ELC-1120	Cable, Level Control, w/ Receptacle	1		

# 1003-10-1 DISCHARGE BASKET ASSEMBLY

