

1003-2-5 Header Conveyor Drive Shaft Assembly

<u>Ref</u>	<u>Part No.</u>	<u>Description</u>	<u>Parts – Assembly</u>	<u>Will Fit SN</u>	<u>Remarks</u>
1	BR-085-RCJ	RCJ Bearing Housing	2	11001	
2	BR-175-085	Fafnir Bearing 1 3/4 Tri Seal	2		
3	BR-175-LC	1 3/4" Locking Collar - Bearing Protector	2		
4	110-112	Shaft, Header Drive	1	11001-	
5	SP-50B16-28-6	Sprocket, Feeder roll drive #50B16 1 3/4 bore	1	11001	
6	SP-60B27-28-6	Sprocket, Header Drive (driven)	1	19101-	
7	SPU-4212-28-6	Urethane Sprocket 42mm x 12 tooth, 1 3/4" x 3/8 key	2		
8	KEY-6-6-24	Keystock 3/8" x 3/8" x 1 1/2" Square Cut (1018)	4		
9	CH-50-41	Roller Chain 41 pitches #50 Feeder Roller w/master link(Pickle & Tomato)	1		
10	CH-60H-51	Roller Chain 51 pitches #60H Header Drive(Tomato & Cucumber) w/master link	1		
11	GF-1428-65	Grease Fitting 1/4" x 28 65	2		

1003-2-5 HEADER CONVEYOR DRIVE SHAFT ASSEMBLY

