

## 1003-3-2 Shaker Chamber Assembly

<u>Ref</u>	<u>Part No.</u>	<u>Description</u>	<u>Parts – Assembly</u>	<u>Will Fit SN</u>	<u>Remarks</u>
1	194-301B	Post, Shaker Side	2	19401-	
2	195-320	Support Brace (Shaker Side)	1		
3	SHD-1898	Shield, Push Offs, Product Deflectors	4		
4	BAR-303	Bar, Angle, Shaker Cover Hook Bar Mount	1		
5	PAN-307	Cover, Diagonal, Top, Tomato	1	KIT-0080	
6	191-312R	Primary Shaker End Cover, Right	1	19101-	
7	191-312L	Primary Shaker End Cover, Left	1	19101-	
8	196-302	Panel, Right-Front Shaker (Tomato)	1	19601-	Replaces 192-302
9	PAN-308	Panel, Right, Rear, Tomato	1	KIT-0080	
10	PAN-309	Panel, Right/Mid, Tomato	1	KIT-0080	
11	196-301	Panel, Left-Front Shaker (Tomato)	1	19601-	Replaces 192-301
12	PAN-306	Panel, Left/Rear	1	KIT-0080	
13	SHD-1893	Deflector, Roller Diverter, Belted Chains, Steel	2		Replaces PL-1893
14	EL-1206	Double Amber Lamp	1		
15	SHD-1206	Shield, Flashing Light	1	30097001- 19601-	
16	193-309	Primary cover stop	2	19301-	
17	BAR-1861	Bar, Roller Backing Plate	6		
18	BAR-302	Bar, Shaker Panel, Front, Top Support	2		
19	RLA-010-0108	Spindle / Standoff for Urethane Roller (heat treated)	2	19101-	
20	RLG-040-1016	4" Urethane Roller	2		
21	RLT-535-228	5" Flange Roller 2.2WF x 3 1/2" dia, 1/2" bore	8		
22	RLR-040-108	4" Flat Roller	2		
23	RLA-000-118	Standoff, 1/2" X 1 1/8"	2		
24	195-312	Cover, Shaker End (Outer)	1	19501-	
25	SHD-1895	Deflector, Roller, Long, Belted Chains, Steel	2		Replaces PL-1895
26	DC-1400	Decal, Secondary Transfer, Yellow	1		
27	DC-1430	Decal, Vine Chain	1		
28	195-304D	Access Door w/Hinge	1		
29	LA-1530	Medium Rubber T Latch Assembly	1		
30	DC-1176	Decal, Danger-Hand Chain Sprockets	1		
150	RI-3-6-SS	SS Pop Rivets, 3/16 x .251-.375, Buttonhead	9		

1003-3-2 SHAKER CHAMBER ASSEMBLY

