

1005-6-2 Cross Conveyor Drive Shaft Assembly

<u>Ref</u>	<u>Part No.</u>	<u>Description</u>	<u>Parts – Assembly</u>	<u>Will Fit SN</u>	<u>Remarks</u>
1	193-806	Mount motor	1		
2	193-806B	Motor Mount Stop	1		
3	BR-062-MPB	Stamped Bearing Housing for 1 1/4" bearing	2		
4	BR-125-062	Bearing, 1 1/4 Fafnir tri-seal, 62mm OD	2		
5	SFT-603	Shaft, Drive, Cross Conveyor	1	19201-19724	Replaces 193-603 on Cross Conveyor
6	SPU-3612-20-4	Urethane Sprocket 36-12 1 1/4 bore 1/4" key	2		Sub SP-3612-20-4
7	KEY-4-4-20	Shaft Key 1/4" x 1 1/4"	1		
8	KEY-4-4-32	Shaft Key 1/4" x 2" Square Cut (1018)	2		
9	HM-204-TC	TCI Motor	1		
10	CPS-6060	Steel Coupler (offcenter) 1 1/4" x 1"	1		
11	SP-50B16-20-4	Sprocket, #50, 16 tooth, 1.25" bore	1		
12	SCR-101	Scraper, Sprocket, Hi Clearance	2		
13	BR-12572-LC	1 1/4" Locking Collar - Bearing Protector	2		
101	BL-5-125-H	5/16-18 X 1 1/4 HEX CAP G5 ZC	1		
600	A-6902-10-8	10 SAE X 1/2" FPX 45	2		
601	H10-94-8MP-8MP	5/8 in hose 1/2MP x 1/2MP x 94 in long	1		
801	KEY-4-4-15	Shaft Key 1/4" X 1/4" X 15/16" Woodruff Key	1		
802	BL-5-100-SF	5/16-24 x 1 Socket Head Cap Screw	4	CPS-6057	

1005-6-2 CROSS CONVEYOR DRIVE SHAFT ASSEMBLY

