

## 1105-3-1 Primary Header Assembly

<u>Ref</u>	<u>Part No.</u>	<u>Description</u>	<u>Parts – Assembly</u>	<u>Will Fit SN</u>	<u>Remarks</u>
1	SUP-8203	Support, Cross Tube, Primary Header, HC290	2		
2	SUP-8204	Support, Mud Pusher, Primary Header, HC290	1		
3	BAR-8200	Bar, Disk Header Mount, High Cap Tomato	2		
4	BAR-8525	Bar, Bolt-on, Primary Header, HC290 Tomato	2		
5	BRA-3525	Bracket, Mount Support, Flex. Head	8	30097001-	
6	FRM-8527	Frame, Outside, Primary Header, HC290 -04 Tomato	1		
7	FRM-8528	Frame, Inside, Primary Header, HC290 -04 Tomato	1		
8	MOU-8225	Mount, Adjuster, Primary Header, High Cap Tom.	2	MOU-8225	
9	PIN-8225	Pin, Adjuster, Primary Header, High Cap Tomato	2		
10	SUP-8205	Cross Tube, Header Control, 290 Tomato Harvester	1		
11	SUP-8202	Support, Cyl Mnt, Disk Header, High Cap Tomato	2		
12	PL-8200	Plastic Shield, Primary Header, HC290 Tomato	2		
13	PIN-250L	1/4" Lynch Pin	2		
14	RLR-040-108R	4" Flat Roller with Replaceable Bearings	8		
15	RLA-000-118	Standoff, 1/2" X 1 1/8"	10		
16	RLT-027-108	Roller 2.75" dia. 1/2" Bore	2		2755C1X (Old Number, Single Bearing)
17	RLS-522-2010	Steel Roller, 5" Flange, 2.2" Dia, 2" wide	2		Sub RLU-522-2010
18	RLA-015-308	Spindle for 3 Point Shakers	2		
19	RLT-324	Rubber 3 Point Shaker	2		
20	RLT-535-228	5" Flange Roller 2.2WF x 3 1/2" dia, 1/2" bore	2		
21	RLT-635-228	6 1/2" Flange Roller 2.2 WF 3.5 dia, 1/2" bore	2		
22	ADJ-3550	Adjuster, Quick Attach Header (Pickle)	2	30096001-	
26	MOU-8201	Cross Mount, Header, 290 Tomato Harvester	2		
101	BL-16-N	1" Nut	8		

# 1105-3-1 PRIMARY HEADER ASSEMBLY

