

1105-8-2 Debris Belt Drive Assembly

<u>Ref</u>	<u>Part No.</u>	<u>Description</u>	<u>Parts – Assembly</u>	<u>Will Fit SN</u>	<u>Remarks</u>
1	ADJ-8501	Adjuster, Belt, Outside, Cross Conveyor, HC290	1		
2	ADJ-8502	Adjuster, Belt, Inside, Cross Conveyor, HC290	1	ADJ-8502	
3	RLR-1036	Roller, Rubber, Flat Belt Drive, 36" Wide, Chili With Keyway	1		
4	BR-062-MPB	Stamped Bearing Housing for 1 1/4" bearing	2		
5	BR-125-062	Bearing, 1 1/4 Fafnir tri-seal, 62mm OD	2		
6	CPS-6060	Steel Coupler (offcenter) 1 1/4" x 1"	1		
7	HM-204-TC	TCI Motor	1		
8	193-806	Mount motor	1		
9	193-806A	Motor mount stop	1		
10	STP-8501	Stop, Outside, Adjuster Belt, Crss Convyr, HC290	1		
11	STP-8502	Stop, Inside, Adjuster Belt, Crss Convyr, HC290	1		
12	BT-86A36L	Debris Belt, 36" Wide x 86 1/2" Long w/A Guide, Laced	1		
12	SHD-8515	Shield, Bearing Cover Protector, 62mm	1		

1105-B-2 DEBRIS BELT DRIVE ASSEMBLY

